

SuperSteer FIT LISTS

Chevy Truck 1500 1999-2006

Steering Play:

- **Idler Arm Support: SS175**
- **Pitman & Idler Brace Kit: SS1506**
- **Idler Arm Support w/ Brace Kit: SS175K6**
- **Heavy Duty Tie Rod Assemblies: SS28723**
- **SS120 Idler Gusset**

Sway:

- **Rear Sway Bar: 1109-167**
- **Motion Control for add-on airbags: SSE4065**
- **Sumo Springs: 99-06(4x4) SSF-203-Front**
- **Sumo Springs- for HD Trucks(2X&4X4) 01-10 SSF-201-Front
SSR-204 -Rear**

Wander:

- **Rear Track Bar: SS625**

Bounce- Porpoising:

- **Shocks**

Overload Springs

- **Super Springs: (99-12) SSA5 or SSA8 heavy duty (mkt required)**
Super Springs (01-10) 1500 HD Trucks SSA10 (mxkt required)



john@SuperSteerParts.com
(888) 898- 3281
SuperSteerParts.com

Chevy Truck 2500/2&4WD
1999-2010

Steering Play:

- **Idler Arm Support: SS175**
- **Pitman & Idler Brace Kit: SS1508**
- **Idler Arm Support w/ Brace Kit: SS175K8**
- **Heavy Duty Tie Rod Assemblies: SS28559**
- **SS125 Idler Gusset**

Sway:

- **Rear Sway Bar: 1109-167**
- **Front Sway Bar: 1109-166**
- **Motion Control for add-on airbags: SSE4065**
- **Sumo Springs- 01-10(2X&4X4) SSF-201-Front**
01-10 (2X&4X4) SSR-201-Rear
11-12 HD Trucks (2x&4x4) SSR-203-Rear

Wander:

- **Rear Track Bar: SS675**
- **Rear Wheel Spacers: SS98-M**

Bounce- Porpoising:

- **Koni Shocks Front 99-10: 8805-1030**
- **Koni Shocks Rear 99-10: 8805-1032**



john@SuperSteerParts.com
(888) 898- 3281
SuperSteerParts.com

Diesel Pusher with Air Ride

Sway:

- **Motion Controls: Measure airline sizes at inlet to airbags.**
 - SSE4045- 1/4 under 30,000 GVW
 - SSE4055- 1/4 over 30,000 GVW
 - SSE5055- 3/8 under 30,000 GVW
 - SSE5065- 3/8 over 30,000 GVW
 - SSE6065- 1/2 under 30,000 GVW
 - SSE6075- 1/2 over 30,000 GVW
 - SSE8085-3/4 under 30,000 GVW
 - SSE8095-3/4 over 30,000 GVW**(Shocks Help Also)**

**** Sway bars are available for some applications. Check ROADMASTER****

Wander:

- **Safety Plus: (Most Take) 41-230**
- **Bracket Kit: Check application**
- **** Optional Trim Unit: Some Applications**
- **IFS limited on Safety Plus kits**
- **Freightliner/Magnum: SS100 (Bell Crank)**

Bounce- Porpoising:

- **Koni Shocks: See Application**



john@SuperSteerParts.com
(888) 898- 3281
SuperSteerParts.com

E350
(VIN# 6-7 digit= E35)

Sway:

- **Rear Sway Bar: (75- UP) 1139-117**
- **Front Sway Bar: (92-Up) 1139-115**
- **Front Sway Bar: (75-91) 1139-100**
- **2" Wheel Spacers -04: SS98-S**
- **(8" on 6 ½ Bolt Pattern 9/16" stud)**
- *****Shocks & Track bars Help also*****
- **Super Springs 01-09- SSA22 SSA13 HD use**

Wander:

- **Safety Plus: 31-140**
- **Bracket Kit (2010 up) E353K14**
- **Bracket Kit: (97-08 V10) E340K13**
- **Bracket Kit: (92-99 V8) E35092K13**
- **Bracket Kit: (92-99 Diesel) E35092DK14**
- **Bracket Kit: (87-91) E350K13**
- **2" Wheel Spacers- 04: SS98-S**
(8" on 6 ½ Bolt Pattern 9/16" stud)

Tailwag-Oversteer:

- **Rear Track Bar: SS402 (with no factory sway bar)**

Bounce- Porpoising:

- **Koni Shocks Front adjustable: (92-12) 82-2553**
- **Koni Shocks Rear adjustable: (92-12) 82-2554**
- **Bilstein Front Comfort: 33-187563**
- **Bilstein Rear Comfort: 33-176-840**
- **Bilstein Front Heavy Duty:33-187563**
- **Bilstein Rear Heavy Duty: 33-176857**



john@SuperSteerParts.com
(888) 898- 3281
SuperSteerParts.com

E450
(VIN# 6-7 digit= E45)

Sway:

- **Rear Sway Bar: 1139-147**
- **Front Sway Bar: (92-08) 1139-115**
- **Front Sway Bar (09& up) 1139-176**
- **Super Springs (01-12) SSA-22 or SSA-25 for HD use**

Wander:

- **Safety Plus: 31-140**
- **Bracket Kit: (97-08 V10) E340K13**
- **Bracket Kit (09 & up) E353K14**

Tailwag-Oversteer:

- **Rear Track Bar: SS450 (For limited fuel tank clearance & factory rear sway bar)**

Bounce- Porpoising:

- **Koni Shocks Front adjustable: (92-12) 82-2553**
- **Koni Shocks Rear adjustable: (92-12) 82-2554**
- **Bilstein Front Comfort: 33-187563**
- **Bilstein Rear Comfort: 33-176840**
- **Bilstein Front Heavy Duty:33-187563**
- **Bilstein Rear Heavy Duty: 33-176857**



john@SuperSteerParts.com
(888) 898- 3281
SuperSteerParts.com

F53/V8
(VIN# 5, 6, 7 digit= F53)
1992 - 1998 14,000-18,000 GVW

Sway:

- **Rear Sway Bar: 1139-143 (1 ½")- Aux Bar**
- **(Rear) Bushing kit (1½ diameter bar):4139-125**
- **Rear Bushing Kit (1 3/8 diameter bar)4139-300**
- **Front Sway Bar: 1139-122**
- **(Front) Bushing kit: 4139-127**
- **Sumo Springs- (90-03) SSF-180- Front
(90-04) SSR-181-Rear
(Shocks & Track bars help also)**

Wander:

- **Safety Plus: 41-140**
- **Bracket Kit: F53K2.5**
- **Rear Track Bar: SS400** With Bolt on differential cover****
- **Front Track Bar: TRAC-F53**

Tailwag-Oversteer:

- **Rear Track Bar: SS400** With Bolt on differential cover****
- **Front Track Bar: TRAC-F53**
- **Safety Plus: 41-140**
- **Bracket Kit: F53K2.5**

Bounce- Porpoising:

- **Koni Shocks Front: 8805-1018**
- **Koni Shocks Rear: 88-1668SP1**
- **Bilstein Front:24-187015**
- **Bilstein Rear: 24-187022**

*****Rear Shocks may need to have metal dust covers removed*****



john@SuperSteerParts.com
(888) 898- 3281
SuperSteerParts.com

F53/V10

1999 & Up 20,000-22,000 GVW

* Newer V10 that has lighter GVW takes the SS400 Track bar (has differential cover)*

Sway:

- **Rear Sway Bar:**
 - **1 ½ diameter: 1139-143 Aux Bar**
 - **1 ¾ diameter (30ft plus): 1139-144 Aux Bar**
 - **1 ½ diameter (Rear ward mounting bar)no drilling mount on: 1139-145 (Tiffin)**
 - **1 ¾ diameter Front Sway Bar: 1139-140**
 - **Sumo Springs (90-03) SSF-181 Front
(04-12) SSF-180 Front
(90-04) SSR-181-Rear
(05-12) SSR-180-Rear**
- (Shocks & Track Bars help also)

Wander:

- **Safety Plus: 41-180**
- **Bracket Kit: (9K axle with 22.5 tires): F53K2.5**
- **Bracket Kit: (1 5/8 tie rod): F119K2.5**
- **Rear Track Bar: SS401 ** Bolt in third member****
- **Rear Trac Bar F5D(24,000 to 26,000GVW) SS525**
- **Front Track Bar: TRAC-V10 up to 2005**

Tailwag-Oversteer:

- **Rear Track Bar: SS401 ** Bolt in third member**20-22,000 GVW**
- **Rear Trac Bar SS400 Bolt on rear diff cover up to 19,000 GVW**
- **Rear Trac Bar SS525 24,000 to 26,000gvw**
- **Front Track Bar: TRAC-V10 up to 2005**
- **Safety Plus: 41-180**
- **Bracket Kit: (9K axle with 22.5 tires): F53K2.5**
- **Bracket Kit: (1 5/8 tie rod): F119K2.5**

Bounce- Porpoising:

- **Koni Shocks Front: 8805-1018**
- **Koni Shocks Rear: 8805-1019**
- **Bilstein Front:24-187039**
- **Bilstein Rear: 24-187046**



john@SuperSteerParts.com
(888) 898- 3281
SuperSteerParts.com

Freightliner XC Chassis Air Ride

Sway:

- **Motion Controls: Measure airline sizes at inlet to airbags.**
 - SSE4045- ¼ under 30,000 GVW
 - SSE4055- ¼ over 30,000 GVW
 - SSE5055- 3/8 under 30,000 GVW
 - SSE5065- 3/8 over 30,000 GVW
 - SSE6065- ½ under 30,000 GVW
 - SSE6075- ½ over 30,000 GVW

(Shocks Help Also)
- **Rear sway bar(95-98): 1209-105 1 ½” diameter**
- **Rear sway bar(93-03): 1209-115 1 ½” diameter**

Wander:

- **Safety Plus:(Solid front axle) 41-230**
- **Bracket Kit: F143K2 (1 ½ tie rod)**
- **Bracket Kit : F143K3 (1 ¾ tie rod)**
- **** Optional Trim Unit: SS200FL**
- **IFS limited on Safety Plus kits**
- **Freightliner/Magnum: SS100 (Bell Crank)**

Bounce- Porpoising:

- **Koni Shocks Front: 8805-1020**
- **Koni Shocks Rear: 8805-1022**
 - ***Solid front axle
- **Koni Shock Front: 88-1641SP3 (Neway IFS)**
- **Koni Shock Rear: 90-1922 (ZF IFS Front End)**



john@SuperSteerParts.com
(888) 898- 3281
SuperSteerParts.com

Freightliner Fred

Sway:

- Rear sway bar: 1209-130 1 ½” diameter
- Front sway bar: 1209-129 1 ¾” diameter

SSF-501 – Front Sumo Springs

(Shocks also help)

Wander:

- Safe-T-Plus Steering Stabilizer: 41-230
- Bracket Kit: H190K2.5
- Trac Bar Front: Trac Fred (Davis Tru Trac by Roadmaster)
- Trac Bar Rear: SS308 SuperSteer

Bounce- Porpoising:

- Koni Shocks Front: 8805-1040
- Koni Shocks Rear: 8805-1041



john@SuperSteerParts.com
(888) 898- 3281
SuperSteerParts.com

Kodiak/Jayco/Seneca C4500/5500

Sway:

- **Rear Sway Bar: 1109-157 1 5/8" diameter Aux**
- **Front Sway Bar: 1109-158 1 5/8" diameter**
- **Rear Super Springs: SSA-22 OR SSA-17 For HD use
(Shocks and Trac Bars help also)**
- **SSF-281 Front Sumo Springs**

Wander:

- **Safety Plus: 41-180**
- **Bracket Kit: (1 3/4 tie rod) C-103K3**
- **Bracket Kit: (1 3/4 tie rod 04' model) S124K3**
- **Rear Track Bar: SS500**
- **Rear Track Bar: (26,000 GVW) SS519**
- **Front Track Bar: TRAC-45-5500**

Tailwag-Oversteer:

- **Rear Track Bar: SS500**
- **Rear Track Bar: (26,000 GVW) SS519**
- **Front Track Bar: TRAC-45-5500**
- **Safety Plus: 41-180**

Bounce- Porpoising:

- **Koni Shocks Front: 8805-1023**
- **Koni Shocks Rear: 8805-1022SP1 (Loop on each end)**
- **Koni Shocks Rear: 8805-1002 (Stem on each end)**
- **Koni Shocks Rear: 90-2530 (Stem on each end 19k Springs)**
- **Bilstein Front(04-11)24-186650**
- **Bilstein Rear(04-11)24-153256(Stem on each end)**
- **Bilstein Front(04-11)24-186650**
- **Bilstein Rear(04-11)24-186667(Loop on each end)**



john@SuperSteerParts.com
(888) 898- 3281
SuperSteerParts.com

P30/32
(Chevy/Workhorse)
1968-2007 IFS

Wander/Play:

- **Bell Cranks (Driver and Passenger side same #): P3032**
- **Bell Crank Arms Driver's side 93 & up (16K Chassis): SS3032-10D**
- **Bell Crank Arms Passenger Side 93 & up (16K Chassis): SS3032-10P**
(.725 measure at small end of taper)
- **Bell Crank Arms Driver's side 91 & earlier (14K Chassis): SS3032-8D**
- **Bell Crank Arms Passenger Side 91 & earlier (14K Chassis): SS3032-8P**
(.665 measure at small end of taper)

*******1992 must measure taper*******

- **Draglink: (11" center to center 92 & up 16K chassis): SS407-16K**
- **Draglink: (13.5" Center to center pre 91 & 14K Chassis) SS842-14K**

Tailwag-Oversteer:

- **Rear Track Bar: SS301U **rear drum brakes****
- **Rear Track Bar: SS300U **rear disc brakes****
- **Rear Tailpipe Kit: SS300TP *Needed if exhaust runs behind rear wheels to install track bar***
- **Safety Plus: 31-140**
- **Bracket Kit: P30KB13**

Sway:

- **Front Sway Bar: 1109-116(narrow track)comes with rear bushing kit***
- **Front Spreader Bar: 1109-200(wide track)**
- **Rear Sway Bar rear bushing kit: 4109-106 (1 3/4)**
- **Front Sway Bar bushing kit: 4109-109 (1 1/4)**
- **EZ Ride: COW501R1D- New Part #251531**
- **Sumo Springs (93-04) SSR-290 Rear**
(OEM rear bump stop installed over spring pack)

(CONTINUED NEXT PAGE)



P30/32
(Chevy/Workhorse)
1968-2007 IFS
Continued

Bounce- Porpoising:

- **Front coil Springs: SS250, SS255,SS260,SS265,SS268**
(Actual front weight is needed to determine spring size)
 1. **Up to 4,300: SS250**
 2. **4,400- 4,900: SS255**
 3. **5,000- 5,300: SS260**
 4. **5,400-5,900: SS265**
 5. **6,000 and Up: SS268**
- **Koni Shocks Front (68-07): 8805-1006**
- **Koni Shocks Rear (68-07): 8805-1007**
- **Bilstein Shocks Front: 24-011730**
- **Bilstein Shocks Rear: 24-015875**
******These Shocks are for standard leaf spring rear suspension******

Misc. Parts:

- **Inner Tie Rod: ES409LT**
- **Outer Tie Rod: ES2000RLT**
- **Upper Control Arm Shaft: K6135**
- **Lower Ball Joint P32: K6511**
- **Lower Ball Joint P30: K6129T**
- **Upper Ball Joint P32: K6174**
- **Upper Ball Joint P30: K6122**
- **Lower Shaft Kit P30: (round style held on w u bolts) K6147**
- **Left Lower Control Arm(flat style) SS17210**
- **Right Lower Control Arm(flat style) SS17211**
- **Steering Gear (93 & up) 16K Chassis: DPSM**
- **Steering Gear 14K Chassis: 2856**
- **Front Air Bags: SS4100**
- **Rear air bags (63-92) **bumpers at bottom of the frame** : 2080**
- **Rear air bags (93& up) ** bumpers above leaf springs** : 2085**



john@SuperSteerParts.com
(888) 898- 3281
SuperSteerParts.com

Roadmaster 8 & 10 Bag Chassis

Sway:

- **Motion Controls: Measure airline sizes at inlet to airbags.**
 - **SSE4045- ¼ under 30,000 GVW**
 - **SSE4055- ¼ over 30,000 GVW**
- **Front Sway Bar: (02-04) 1169-108 * Center Rear Radiator**
- **Front Sway Bar: (05-09) 1169-110 * Side mount Radiator**
- **Rear Sway Bar: (02-09) 1169-109 * Center Rear Radiator**

Wander:

- **Safety Plus: (Most Take) 41-230**
- **Bracket Kit: G002K4**
- **** Optional Trim Unit: SS200RM**

Bounce- Porpoising:

- **Koni Shocks Front:(8 bag 03-07) 8805-1016**
- **Koni Shocks Rear :(8 bag 03-07) 8805-1017**
- **Koni Shocks Front: (8 bag 93-02)8805-1004**
- **Koni Shocks Rear: (8 bag 93-02)8805-1005**
- **Koni Shocks Rear: (8 bag 93-02)8805-1005**
- **Koni Shocks Front: (10bag 93-07)8805-1004**
- **Koni Shocks Rear: (10 bag 93-07)8805-1005**



john@SuperSteerParts.com
(888) 898- 3281
SuperSteerParts.com

W16/W18
(VIN# 6 digit= E)

Sway:

- **Rear Sway Bar: (05-12) 1259-118**
- **Front Sway Bar: 1259-115**
*****Shocks & Track bars help also*****

Wander:

- **Safety Plus: 41-230**
- **Bracket Kit: W104K1.5**
- **Rear Track Bar: SS306**
- **Front Track Bar: TRAC-W16/W18**

Tailwag-Oversteer:

- **Rear Track Bar: SS306**
- **Front Track Bar: TRAC-W16/W18**
- **Safety Plus: 41-230**
- **Bracket Kit: W104K1.5**

Bounce- Porpoising:

- **Koni Shocks Front: 8805-1001**
- **Koni Shocks Rear: 8805-1003**
****** Just 05' and up******



john@SuperSteerParts.com
(888) 898- 3281
SuperSteerParts.com

W20/W22/W24
(VIN# 6 digit= 6)

Sway:

- **Rear Sway Bar: 1259-108 (1 ½")**
 - **Rear Sway Bar: 1259-109 (1 ¾")**
 - **Front Sway Bar: 1259-105 (1 ½")**
 - **Sumo Springs (01-10) SSF-280 Front
(01-10) SSR-280 Rear**
- ***Shocks & Track bars help also*****

Wander:

- **Safety Plus: 41-230**
- **Bracket Kit: W104K1.5**
- **Rear Track Bar: SS302**
- **Front Track Bar: TRAC-W20/W22/W24**

Tailwag-Oversteer:

- **Rear Track Bar: SS302**
- **Front Track Bar: TRAC-W20/W22/W24**
- **Safety Plus: 41-230**
- **Bracket Kit: W104K1.5**

Bounce- Porpoising:

- **Koni Shocks Front(99-03): 8805-1001**
- **Koni Shocks Front (04 & up): 8805-1001**
- **Koni Shocks Rear(99-03): 8805-1003**
- **Koni Shocks Rear (04 & up): 8805-1002**
- **Bilstein Front(05-11)24-153249**
- **Bilstein Rear(05-11) 24-153256**

*****Look at the rear shock mounting style 8805-1002 has a stem on each end. 8805-1003 has an eyelet on top and a stem on the bottom*****

*****Some '04 have '03 style shocks on the rear*****



john@SuperSteerParts.com
(888) 898- 3281
SuperSteerParts.com

Sprinter Chassis - Dodge, Freightliner, Mercedes 2500 & 3500

Steering/ Wander:

- **Steering Control Steer Safe (04-07) 2500 & 3500 (MERC/SPRINTER)**
- **Steering Control Steer Safe (08 & UP) 3500 (MERC/SPRINTER 08)**

SWAY:

- **Rear Sway Bar:**
- **Roadmaster (07-12) 3500 AUX. 1.5 1209-131**
- **(04-06) 3500 AUX. 1.5 1209-132**
- **(08-09) 3500 1 3/8" 1209-120**
- **(04-May of 07) 3500 1 3/8"1209-118**
- **(08-09) 2500 1 1/8" 1209-128**
- **(02-07) 2500 1 1/8" 1209-117**
- **Sumo Springs (03-12) 2500 SSR-325**
- **Rear Overloads:**
- **SuperSprings (03-09) 2500 factory steel leaf SSA11 + MTKT required**
- **(03-09) 3500 factory steel 3 leaf SSA12+ MTKT required**

Bounce / Porpoising :

- **2500 w/ 2.4 L engine 03-06 Koni Front Shocks 87-2604 Rear 82-2434**
- **2500 w/15" wheels 2002 Koni Front Shocks 87-2604 Rear 82-2434**
- **2500 All other03-06 Koni Front Shocks 87-2638 Rear 82-2434**
- **3500 03-06 Koni Front Shocks 87-2638 Rear 82-2440**
- **2500 07-2013 Koni Front Shocks 87-2656 Rear 82-2585**
- **3500 07-13 Koni Front Shocks 87-2657 Rear 82-2588**

- **Bilstein Shocks Rear (03-06) 2500 & 3500 24-177702**
- **Bilstein Shocks Rear (07-09) 3500 24-167161**



Motorhome Applications



Vehicle	Year	Front	Notes	Rear	Notes
Beaver					
Magnum Air 8 bag		see Safari			
Gillig Chassis		90-2164SP1			
Bluebird Wanderlodge					
LX, Lxi, Forward Control	-01	90-2497SP1	A	9005-1025	
Tag axle (non-steerable)				8805-1010	
Tag Axle (steerable)				8805-1015	F
M380, 450LXi	02-	9044-1005		8844-1006	D
Tag axle				8844-1007	
Chevrolet					
P30 / P32 / P3500	68-99	8805-1006		8805-1007	
Country Coach					
Affinity, Concept, Magna, MAT					
Gillig Chassis w/Neway					
Ridewell Suspension					
Neway IFS					
Contact Your Local Dealer					
Allure, Intrigue					
Gillig Suspension					
Neway IFS					
Reyco Suspension					
Dodge Ram Pickup 4 W.D.					
2500 excl Power Wagon	03-08	8805 1037		8805 1039	
2500 w/ 8800 GVW	94-02	8805 1037		8805 1038	
3500 excl Chassis Cab	03-08	8805 1037		8805 1039	
3500 Series 1 T	94-02	8805 1037		8805 1038	
Eagle					
Model 10		90-1898	C	90-1898	B
Tag axle				90-1898	B
Fleetwood American Dream					
Reyco/Gillig or Spartan		88-1458SP2		88-1457SP1	B
Ford					
E-350, E450	92-07	82-2553		82-2554	
F53 Super Duty V8	88-98	8805-1018		88-1668SP1	
F53 Triton V10	99-11	8805-1018		8805-1019	
Featherlite					
Vogue III w/ Crown chassis		90-1867		90-1868	
Vogue	- 99			90-1943SP4	
Tag Axle				80-1490	
Foretravel					
U225, U-240 w/ velvetride	91-95	88-1490SP2		90-2256SP1	C
U-280, 295, 300, 320 Series		8805-1010	D	8805-1010	D
Tag axle				8805-1011	
Freightliner					
FL 60 w/airliner rear susp.				8805-1022	E
FRED (front engine diesel)		8805-1040		8805-1041	
XC w/rigid front axle	02-11	8805-1020		8805-1022	
XC w/ Neway IFS	93-07	88-1643SP3		8805-1022	
XC w/ZF IFS	02-11	90-1922		8805-1022	
XCS - steel leaf spring only		88-1668SP1			
GMC/Chevrolet					
C5500 Kodiak, C4500		8805-1023		8805-1002	II
				8805-1022SP	oo
19(K)lb Rear Axle				90-2530	II
Classic Bus		90-2575		90-2576SP1	
RTS Bus		90-2433SP1		90-2434SP2	
P3500 Class A-Motorhome		8805-1006		8805-1007	

- A. Adjust 1 full turn
- B. Adjust 1.5 turns
- C. Adjust to Maximum
- D. Requires [4] shocks per axle
- E. Requires Kit FL60 spacer kit
- F. Special Order

* may require lower mounting brkt from Spartan

0924-DD1-801038	lower shock brkt	2
12100350H8B	bolt	2
1210FLN8B	nut lock	2
12FWSAEB	flat washer	2

Vehicle	Year	Front	Notes	Rear	Notes
GMC Chevrolet Silverado Pickup					
3/4T 2WD up to 8600 gvw	99-06			8805 1032	
3/4T 4WD up to 8600 gvw	99-07	8805 1030		8805 1032	
3/4T 2&4 WD 9200 gvw	00-07	8805 1030		8805 1032	
1T 2&4WD w/IFS	01-07	8805 1030		8805 1031	

Monaco					
S Series Chassis - Dynasty/Executive/Signature/Navigator					
4 shocks/axle (eye/eye)	93-02	8805-1004	D	8805-1005	D
10 Bag Coach	93-07	8805-1004	D	8805-1005	D
Tag axle	93-07			8805-1005	
RR8R Chassis - Diplomat/Endeavor					
4 shocks/axle (pin/eye)	03-11	8805-1016	D	8805-1017	D
RR8S Chassis - Camelot/Diplomat/Windsor					
	02-11	TBA		TBA	
Camelot/Sceptor/Contessa	04-07	TBA		TBA	
Ambassador, Cayman, Knight, Neptune (R4R, RR4R)					
4 Bag (2 shocks/axle)	02-11	8805-1021		8805-1022	

Motor Coach Industries					
D - Coach		90-2586	F	90-2587	F,D
Tag axle				90-2588	F
E-Coach		90-2755		9005-1018	
				9005-1019	
J-Coach		90-2816		9005-1018	
Tag axle				9005-1019	

Peak Chassis					
Alpine Coach		8805-1021		8805-1022	
Prevost					
H3, XL w/ rigid front axle		90-2572		90-2573	D
Tag axle				90-2573	
H3, XL, XLII w/ IFS		90-2574		90-2573	D
Tag axle				N/A	

Safari					
Magnum Air 8 Bag	96-00	8805-1004SP1	D	8805-1005SP1	D
Magnum Air 4 Bag	92-01	88-1490SP2		88-1458SP2	
Magnum w/velvetride	95-00	88-1490SP2		88-1458SP2	
Magnum w/leaf spring	93-99	8805-1010		88-1458SP2	
Ridewell Frt, RAD 227 Rr		90-1968		90-1868	
Reyco 1212 Frt, 102AR Rr		88-1458SP1		88-1457SP1	
Alpine/Summit	97-01	88 1641SP3		8805-1022	
MC 2000	91-95	8805-1021		88-1457SP1	
Mountainmaster I-Beam	96-04	8805-1021		8805-1009	
Mountainmaster IFS w/Tuthill Suspension					
IFS1200	GVWF under 13,000#	97-04	90-2815	8805-1009	
IFS1260	GVWF under 13,000#	97-04	TBA	8805-1009	
IFS1360	GVWF between 13,000 - 14,000#	98-04	90-2815	8805-1009	
IFS1460	GVWF between 14,000 - 16,000#	00-	90-2890	* 8805-1009	
IFS1660	GVWF over 16,000 #	04-	90-2890	* 8805-1009	
K2, K3 (16,000 +)		04-	90-2890	* 8805-1009	
tag axle				8805-1013	
Hendrickson I Beam - Airtek w/ HA 08-		TBA		TBA	
Hendrickson tag axle				8805-1013	
Hendrickson I Beam - Airtek w/ HT 08-		TBA		TBA	
Hendrickson tag axle				8805-1013	

Sprinter					
2500 w/ 2.4 L engine	03-06	87 2604		82 2434	
2500 w/ 15" wheels	2002	87 2604		82 2434	
2500 all other	03-06	87 2638		82 2434	
3500	03-06	87 2638		82 2440	
2500	07-13	87-2656		82-2585	
3500	07-13	87-2657		82-2588	

Workhorse					
UFO	07-09	8805-1021		8805-1002	
P30/P32/Widetrack IFS	99-05	8805-1006		8805-1007	
W16-W18	05+	8805-1001		8805-1003	
W20-W24	01-04	8805-1001		8805-1003	
W20-W24	05-11	8805-1001		8805-1002	

